




# Gas room sealed unit heaters 2 stage

## TECHNICAL INFORMATION ASSEMBLY INSTRUCTIONS, USE AND MAINTENANCE

### RS/UHA-2



BENSON HEATING  
LUDLOW ROAD  
KNIGHTON  
POWYS  
LD7 1LP

MAY 2003

Benson Heating is a division of  
Benson Climate Systems Ltd

## COMPLIANCE NOTICES

The Benson RS/UHA2 range of warm air heaters detailed herewith are manufactured for Benson Heating within the parameters of ISO 9002.

The Benson RS/UHA2 Range has been independently tested and assessed, and has been found to meet the Essential Requirement of the following European Directives:

Gas appliance Directive (90/396/EEC)  
Machinery Directive (89/392/EEC) 91368/EEC 93/44/EEC 93/65/EEC  
Low Voltage Directive (73/23/EEC)  
Electromagnetic Compatibility Directive (98/336/EEC and 91/31/EEC)  
Product Liability Directive (65/374/EEC)

The manufacturer has taken reasonable and practical steps to ensure that Benson RS/UHA2 Range of Heaters are safe and without risk when properly used. These heaters should therefore only be used in the manner and purpose for which they were intended, and in accordance with the recommendations detailed herewith.

The heaters have been designed, manufactured, assembled, inspected, and tested, with safety and quality in mind, there are certain basic precautions which the installer and user should be aware of, and they are strongly advised to read the appropriate sections of the information pack accompanying the heater, prior to installation or use.

Benson Heating supports all new products being supplied to their customers with a comprehensive information pack; this clearly defines mandatory instructions for the safe installation, use, and maintenance, of the appliance(s).

Where proprietary items are incorporated into Benson Heating products, detailed information and instructions are also provided as part of the information pack.

It is the responsibility of the installer, owner, user, or hirer, of such products supplied by Benson Heating, to ensure that they are familiar with the appropriate information/manuals, supplied by the manufacturer, and that they are suitably aware of the purpose of the manuals and the safety instructions. In addition, operators must be suitably trained in the use of the appliance so as to ensure its continued safe and efficient use.

Benson Heating has a commitment to continuous improvement, and therefore reserves the right to amend or change the specification of the RS/UHA2 Heater range subject to agreement from The Notified Body.

Contained within the text of the manual, the words '**Caution**' and '**Warning**' are used to highlight certain points.

**Caution** is used when failure to follow or implement the instruction(s) can lead to premature failure or damage to the heater or its component parts.

**Warning** is used when failure to heed or implement the instruction(s) can lead to not only component damage, but also to a hazardous situation being created where there is a risk of personal injury.

**Notified Body PIN Reference is**

### RANGE

<i>Type</i>	<i>Model</i>	<i>Code</i>
1	RS/UHA2 50	3TAIT2C016
2	RS/UHA2 80	3TAIT2C026
3	RS/UHA2 105	3TAIT2C036
4	RS/UHA2 140	3TAIT2C046
5	RS/UHA2 200	3TAIT2C066
6	RS/UHA2 260	3TAIT2C086
7	RS/UHA2 325	3TAIT2C106

## INDEX

### GENERAL

Description of equipment	page.
Identification	“
Description	“
Identification	“
Description	“
Technical data	“
Wiring diagram	“
Remote control connections	“
Regulating air flow	“

### FOR THE USER

Operation	“
Servicing	“
Heater indication lights	“
Receipt of product	“
Transport	“
Dimension	“


### FOR THE INSTALLER

Location	“
Wall bracket dimensions	“
Gas connection	“
Flue and combustion options	“
Electrical control panel	“
Electrical connections	“

### TECHNICAL ASSISTANCE SERVICE

Pre commissioning checks	“
Initial start up	“
Gas conversion	“
Thermostat operation	“
Control	“
Maintenance	“
Fault finding	“

## Heaters type 1-2-3-4-5




### KEY:

<b>SND</b>	Temperature probe	<b>PA</b>	Differential pressure switch
<b>TR</b>	Regulatory control thermostat (auto reset)	<b>IGN1</b>	Ignition transformer
<b>LM</b>	LIMIT thermostat (manual reset)	<b>EA1</b>	Spark electrode
<b>EVG1-I°</b>	Gas solenoid valve1	<b>ION</b>	Ionisation probe
<b>EVG1-II°</b>	Second stage gas valve 2	<b>SE</b>	Electrical control board
<b>C</b>	Fan capacitor	<b>IMT (*)</b>	Fused isolator
<b>FAN 1</b>	Axial fan 1	<b>MS (*)</b>	Fire damper connection (accessory)
<b>FAN 2</b>	Axial fan 2 (type 5)	<b>RSTR (*)</b>	Remote reset connection
<b>F1-F2</b>	Line fuse (6,3 A)	<b>TA (*)</b>	Room thermostat connection
<b>LF</b>	Green working light	<b>VM (*)</b>	Fan switch connection
<b>LL</b>	High temperature indication light	<b>SF (*)</b>	Second stage gas valve connection
<b>LB</b>	Lockout indication		
<b>RST</b>	Lockout reset		
<b>EF</b>	Flue venter		

(\*) External to the heater customer supply.

# Heater type 6-7



**KEY:**

- SND** Temperature probe
- TR** Regulatory control thermostat (auto reset)
- LM** LIMIT thermostat (manual reset)
- EVG1-I°** Gas solenoid valve 1
- EVG2-I°** Gas solenoid valve 2
- EVG1-II°** Second stage gas valve 1
- EVG2-II°** Second stage gas valve 2
- C** Fan capacitor
- FAN 1** Axial fan 1
- FAN 2** Axial fan 2
- FAN 3** Axial fan 3(Type 7)
- F1-F2** Line fuse
- LF** Green working light
- LL** High temperature indication light
- LB** Lockout indication

- RST** Lockout reset button
- EF** Flue venter
- PA** Differential pressure switch
- IGN1** Ignition transformer 1
- IGN2** Ignition transformer 2
- EA1** Spark electrode 1
- EA2** Spark electrode 2
- ION** Ionisation probe
- SE** Electrical control board
- IMT (\*)** Fused isolator
- MS (\*)** Fire damper connection (accessory)
- RSTR (\*)** Remote reset connection
- TA (\*)** Room thermostat connections
- VM (\*)** Fan switch connections
- SF (\*)** Second stage gas valve connection

(\*) External to the heater customer supply.

## GAS CONVERSION

The heaters are supplied ready for use with (G20) Natural Gas as per the table below Conversion kits are available from the manufacturer:

### Natural Gas (G20)

TYPE	1	2	3	4	5	6	7	
Number of injectors	1	1	1	1	2	2	4	N°
Diameter of injectors	3,10	410	480	555	500	540	450	mm/100
Gas supply pressure	20							
Head pressure high fire	11,0	13,0	13,0	13,0	10,0	13,0	10,5	mBar
Head pressure low fire	6,0	7,0	6,5	6,5	7,0	6,5	5,0	mBar

### BEFORE CHANGING INJECTORS ENSURE GAS SUPPLY IS ISOLATED

#### INSTRUCTIONS FOR CONVERSION TO PROPANE GAS G(31)

1. Change the injectors
2. Adjust the gas inlet pressure
3. Adjust the head pressure
4. Fit primary air diaphragm (if required )
5. Fit adhesive label supplied with kit indicating gas type
6. Ensure settings are correct as per the manual and data plate

#### CHANGE INJECTORS:


To change injectors:

Unscrew the natural gas injectors and replace them with the correct size injectors for propane as shown in table below:


### Propane gas (G31)

TYPE	1	2	3	4	5	6	7	
Number of injectors	1	1	1	1	2	2	4	N°
Diameter of injectors	190	250	280	335	285	320	255	mm/100

Replacing injectors single manifold (type 1-2-3-4-6)



Replacing injectors 2 per manifold (type 5-7)



Check the size stamped on the side of the injector is correct to the data in the manual.



Ensure that the new injectors are correctly fitted in the manifold and are gas tight, When the conversion is complete fix the transfer supplied

with the kit showing the correct gas pressure on to the manifold

Test for gas soundness on completion

Ensure that the aluminium washers supplied for (types 5-7) are fitted when changing the injectors.

If the gas line has not been correctly purged ignition may not take place at the first attempt resulting in the heater going to lockout  
Reset the lockout before re starting ignition sequence

**! Before each attempt at ignition it is necessary to wait at least 10 seconds**

- Connect the manometer on to the pressure test point PM and check inlet gas pressure if correct connect manometer to test point PV and start heater with heater running ensure the gas pressure corresponds to that shown on the data plate adjust by altering the screws RP1 and RP2 on the gas valve
- Check that the gas consumption reading corresponds with that indicated in the TECHNICAL DATA section Set on/standby switch to standby when heater is sufficiently cool isolate gas supply
- Remove manometer ensure the screw at the test point is tightened test for gas leaks
- Open the gas isolating cock switch on the electrical supply set the room thermostat to the desired temperature.
- The heater is now ready for operation

#### **GAS VALVE**

**Model SIT 843 (two stage)**



**The heater must only be operated with the burner compartment door(s) closed**


#### **STOPPING**

To stop the heater use only the room thermostat Set it to the minimum temperature The fan will stop after 3 minutes or when the heat exchanger is sufficiently cool If required switch off the electricity supply at the isolator



**The main electrical supply must not be switched off or used as a method of stopping the heater except in an emergency until the heater has cooled down sufficiently preventing damage to the heat exchanger**

**Interruption of electrical supply whilst heater is in operation will cause it to go to overheat and may damage the heat exchanger the LIMIT thermostat will operate and this will have to be manually re set.**



- PM** Inlet pressure test point.  
**PV** Head pressure test point  
**RP1** Cross cut screw low fire adjuster  
**RP2** Hexagonal screw high fire adjuster

**Assembly of primary air diaphragm:**

Diagram showing the fitting of a primary air diaphragm to single burner manifold (1-2-3-4-6)





Diagram showing the fitting of a primary air diaphragm for a two burner manifold type (7)



**!** Warning the diaphragm plates should only be used when using propane gas G31.

**Gas conversion adhesive label:**

Once the heater has been converted to propane ensure that the correct label is fitted to the burner overtop of the factory fitted one covering it completely. It is recommended that the diameter of the nozzles be checked also that the pressure corresponds to that shown on the data plate provided

Ensure that all of the additional gas components are correct for the installation (including storage tank, pipes and pressure valves etc

Ensure that the pressure regulators are sealed after carrying out the conversion.

**GAS PRESSURE REGULATION**

**To regulate the gas inlet pressure :**

- Connect a manometer onto the gas valve test point **(PM)**
- Adjust the inlet gas supply regulator (customer installation) to pressure indicated on data plate:

**To regulate the gas head pressure to the burner:**

- Connect a manometer onto the gas valve test point **(PV)**
- Adjust the pressure regulating adjusters RP1/ RP2 as detailed on next page to obtain correct pressures indicated in table below:

**Propane gas (G31)**

TYPE	1	2	3	4	5	6	7	
Gas supply pressure	37							mBar
Head pressure max	35,5	35,0	35,5	35,5	34,5	35,5	34,5	mBar
Head pressure min	20,0	18,0	18,5	18,0	18,0	18,0	18,5	mBar

**!** Gas inlet pressure must not exceed 60 mbar at the gas valve inlet.



**Gas valve head pressure setting high fire Propane G31:**

When setting the gas pressure for propane high fire (second stage ) contact SF should be closed the high fire pressure adjusting screw on the gas valve must be excluded.  
Connect a manometer on test point PV


Remove the plastic cover from the adjuster **RP1 RP2**  
With a screw driver hold the adjuster RP1 stationary and using a spanner, screw adjuster RP2 clockwise to the bottom of the thread until the correct pressure according to the data plate is achieved .

**Gas valve head pressure setting low fire Propane G31 :**

When setting the gas pressure for propane low fire (first stage) contact SF should be open. The low fire pressure should be adjusted to the settings shown on the data plate and the data in the manual provided by adjusting screw RP1  
Clockwise increases the pressure

Anti clockwise to decrease the pressure  
On completion replace the plastic cover and seal with paint  
Remove manometer ensuring that the test point screw is gas tight

**Gas valve gas SIT 843**



 On heaters with 2 gas valves the pressure regulation must be carried out on both gas valves

## FAULT FINDING

If the heater is not working firstly check the following :

- Check electrical supply
- Check voltage is as stated +15%, -15%
- Check gas supply is on
- Check that the pressure is as stated in the TECHNICAL DATA

FAULT	CAUSE	SOLUTION
<p><b>No operation</b></p>	<p>No electrical supply</p>	<p>Check main isolator. Check supply cables Check line fuses. Check electrical connections</p>
<p><b>No spark ignition.</b> <i>Flue venter working</i> <i>No indication lights on</i></p>	<p>Differential pressure switch not working</p>	<p>Check flue pipe and combustion air pipe are clear.</p>
	<p>Faulty differential pressure switch</p>	<p>Replace differential pressure switch</p>
	<p>Poor connection at pressure switch</p>	<p>Check air pipe to switch is connected and not damaged Check electrical connections Check that pipes are condensate free .</p>
	<p>Faulty flue venter</p>	<p>Replace flue venter</p>
	<p>Faulty control panel</p>	<p>Replace control panel</p>
	<p>Faulty ignition electrode</p>	<p>Check ignition probe is not cracked or damaged Replace the ignition probe</p>
<p><b>No ignition</b> <i>Flue venter working</i> <i>No indication lights on</i></p>	<p>Room thermostat open</p>	<p>Check room thermostat.</p>
	<p>Faulty flue venter</p>	<p>Replace flue venter</p>
	<p>Faulty control panel</p>	<p>Replace control panel</p>

**Burner lights but locks out after 5 seconds**

▶ Live and neutral inverted  
Poor earth

▶ Check electrical connections

▼  
Faulty ionisation probe

▶ Check electrical connection on probe.  
▶ Check probe for cracks or damage.  
▶ Replace ionisation probe .

▼  
Faulty ignition

▶ Check the gas type is suitable for the heater.  
▶ Check the inlet gas pressure.  
▶ Check the head pressure.  
▶ Check the gas supply pipes have been properly purged of air .

**Explosive start up.**

▶ Faulty ignition electrode

▶ Replace ignition electrode

▼  
Incorrect electrode position

▶ Reposition electrode correctly over the burner bar.

▼  
Faulty burner tube

▶ Replace the burner tube

▼  
Faulty ignition transformer

▶ Replace ignition transformer

▼  
Faulty ignition

▶ Check the gas type is suitable for the heater.  
▶ Check the inlet gas pressure.  
▶ Check the head pressure.  
▶ Check the gas supply pipes have been properly purged of air .

▼  
heat exchanger dirty

▶ Check / clean heat exchanger

**Burner shuts down then re lights automatically .**  
*No indication lights on.*

▶ Pressure differential switch not operating correctly

▶ Check that air pipe to switch not damaged or blocked.  
▶ Check that the flue and combustion air pipes are clear.  
▶ Check that the thermal overload on the flue venter has not operated

▼  
Faulty pressure differential switch

▶ Replace differential switch

▼  
Room thermostat in warm air flow

▶ Check position of thermostat

**Burner goes out due to the intervention of the SND thermostat and is restarted automatically when the heater has cooled down .**

*Yellow indication light on.*

▶ Excessive heat exchanger temperature ▶

Check inlet gas pressure  
Check burner head pressure  
Check that gas type is suitable for heater  
Check injector size is correct for the heater.

▼  
Excessive air temperature due to insufficient air flow over heat exchanger. ▶

Check the fan blades are clean  
Check that the horizontal and (vertical if fitted) louvers are sufficiently open. (see in installation section of manual)  
Check that the fan speed is correct and the air flow over the chamber is sufficient.

▼  
Faulty SND thermostat or control panel ▶

Replace SND thermostat or control panel

**Burner goes out due to the intervention of the TR thermostat and is restarted automatically when the heater has cooled down .**

*Yellow indication light on.*

▶ Excessive heat exchanger temperature ▶


Check inlet gas pressure  
Check burner head pressure  
Check that gas type is suitable for heater  
Check injector size is correct for the heater.

▼  
Excessive air temperature due to poor air flow ▶

Check the fan blades are clean  
Check that the horizontal and (vertical if fitted) louvers are sufficiently open. (see in installation section of manual)  
Check that the fan speed is correct and the air flow over the chamber is sufficient.

▼  
Faulty thermostat ▶

Replace thermostat



**The control panel will not reset .**  
*Red light on*



Faulty flame control module



Replace the flame control module after first checking the electrical connections

**Fan works intermittently**



Defective fan control



Change fan control or SND thermostat



Insufficient gas pressure



Check that the gas type is suitable for the heater .  
Check the gas pressure  
Check burner head pressure.

**The fan does not work.**



Defective fan control



Change fan control or SND thermostat



Faulty fan



Check fan capacitor.  
Check the fan motor .

**The heater works continuously with out reaching the required temperature**



Heater too small for application  
Insufficient gas pressure



Re check heat output required for the application  
Check that the gas type is suitable for the heater .  
Check gas pressure.  
Check burner head pressure.




Dirty heat exchanger



Clean heat exchanger

**B<sub>22</sub>: Single flue option with condensate tee and roof terminal combustion air from inside the room**

Type 1 – 2 – 3 – 4



*	157 mm type 1 – 2 – 3
	165 mm type 4

ITEM	DESCRIPTION
A	Pipe M/F Ø100 L=1000 with seal
T	Terminal with guard Ø100
U	Condensate Tee with drain point
V	Pipe M/M Ø100 L=200 without seal


**NOTE IMPORTANT:**

MODEL	1-2-3-4
Ø FLUE SPIGOT	Ø100 female
Ø COMBUSTION AIR SPIGOT	Ø100 female
INSTALLATION	Flue should be adequately supported each bend corresponds to approx 0,8-1 meter of horizontal pipe work



**B<sub>22</sub>: Single flue option with condensate tee and roof terminal combustion air from inside the room**

Type 5 – 6 – 7




ITEM	DESCRIPTION
A	Pipe M/F Ø100 L=1000 with seal
T	Terminal with guard Ø100
U	Condensate tee with drain point
Z	Pipe M/F Ø100 L=250 with seal

**NOTE IMPORTANT:**

<b>MODEL</b>	5-6-7
<b>Ø FLUE SPIGOT SIZE</b>	Ø100 male
<b>Ø COMBUSTION AIR SPIGOT SIZE</b>	Ø150 male
<b>INSTALLATION</b>	Flue should be adequately supported Each bend corresponds to approx 0,8-1 meters of horizontal pipe work

## C<sub>32</sub> Installation showing Vertical co axial flue terminal with condensate drain

Type 1 – 2 – 3 – 4




ITEM	DESCRIPTION
A	Flue pipe M/F Ø100 L=1000 with seal
H	Bend 90° M/F Ø100 with seal
L	Vertical co axial roof terminal kit Ø100-100
U	Condensate tee with drain point
V	pipe M/M Ø100 L=200 without seal

### NOTE IMPORTANT:

MODEL	1-2-3-4
Ø FLUE SPIGOT SIZE	Ø100 female
Ø COMBUSTION AIR SPIGOT SIZE	Ø100 female
INSTALLATION	Flue should be adequately supported each bend corresponds to about 0,8-1 meters of horizontal pipework

## C<sub>32</sub> Installation showing Vertical co axial roof terminal with condensate drain

Type 5 – 6 – 7



ITEM	DESCRIPTION
A	Pipe M/F $\varnothing 100$ L=1000 with seal
F	Pipe M/F $\varnothing 150$ L=1000 with seal
I	Bend 90° M/F $\varnothing 150$ with seal
N	Vertical co axial roof terminal kit $\varnothing 100$ -150
P	Adaptor F/F $\varnothing 150$ L=200 with seal
Q	Bend 45° M/F $\varnothing 150$ with seal
R	Pipe M/F $\varnothing 150$ L=140 with seal
S	Bend 90° F/F $\varnothing 100$ with seal
U	Condensate tee with drain point
Z	Pipe M/F $\varnothing 100$ L=250 with seal

### NOTE IMPORTANT:

MODEL	5-6-7
$\varnothing$ FLUE SPIGOT SIZE	$\varnothing 100$ male
$\varnothing$ COMBUSTION AIR SPIGOT SIZE	$\varnothing 150$ male
INSTALLATION	Flue should be adequately supported each bend corresponds to about 0,8-1 meters of horizontal pipework